



2012+ 1770NT John Deere™ Visagage II

Installation Kit

116151 (8 Row)

116108 (12 Row)

116107 (16 Row)


116150 (24 Row)

WARNING: USE OF THIS PRODUCT FOR ANY PURPOSES OTHER THAN ITS ORIGINAL INTENT, ABUSE OF THE PRODUCT, AND/OR MODIFICATION TO THE ORIGINAL PRODUCT IS STRICTLY PROHIBITED BY CDS-JOHN BLUE COMPANY. CDS-JOHN BLUE COMPANY RESERVES THE RIGHT TO DENY WARRANTY OR LIABILITY CLAIMS IN ANY/ALL SITUATIONS INVOLVING MISUSE, ABUSE OR MODIFICATION.

FAILURE TO FOLLOW THIS NOTICE MAY RESULT IN SERIOUS INJURY AND/OR PROPERTY DAMAGE AND WILL VOID THE PRODUCT WARRANTY. IF IN DOUBT ABOUT YOUR APPLICATION, CONTACT YOUR STOCKING DEALER OR THE CDS-JOHN BLUE TECHNICAL STAFF AT 1-800-253-2583.

Installation:

1. Disconnect tubing from manifold by pushing in on release ring, and pulling out on tubing. Remove hardware holding manifolds to brackets, but be sure to keep the bolts and nuts for later use. Repeat process on other side of planter.




2. Install elbow fittings into Visagage II columns using liquid Teflon or pipe joint compound. For a 16 row planter, a set of 8 columns will be installed on each bracket, for a 12 row planter a set of 6 columns will be installed on each bracket, etc... The columns can be joined together before assembly to the bracket using the supplied bolts - be sure to arrange the backing plates as shown below:

16 row backing plates (116111-01) shown
8 row planters use one plate (116111-01) per bracket
12 row plates (116110-01) have 3 sets of holes each
24 row plates (116136-01) have 6 sets of holes each

Arrange backing plates and center Visagages on mounting bracket as shown


116109-01 Mounting plate
(two per planter)



Attach Visagages to backing plates and mounting plate with 1/4" x 2" lg bolts, 1/4" nuts, and lockwashers.
DO NOT OVERTIGHTEN

Install 116113-01 elbow fittings into Visagage columns using liquid Teflon or joint compound

3. Attach inlet tubes (lower fittings) to manifold ports, and attach outlet tubes (upper fittings) to original lines on planter using supplied couplings. Middle lower fittings should be aimed through holes in bracket.



4. Attach mounting bracket onto manifold using the original bolts and nuts. Note: feed the bolts from the bottom of the bracket and place the nuts on top. *Do not over tighten!* (5 ft-lbs max)

LIMITED WARRANTY

THIS WARRANTY IS IN LIEU OF ALL OTHER WRITTEN OR EXPRESS WARRANTIES AND REPRESENTATIONS. ANY IMPLIED WARRANTIES INCLUDING MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO THIS WRITTEN WARRANTY. CDS-JOHN BLUE COMPANY SHALL NOT BE LIABLE FOR CONSEQUENTIAL DAMAGES.

Use of this product for any purpose other than its original intent, abuse of the product, and/or any modification to the original product is strictly prohibited by the manufacturer, CDS-John Blue Company. Any modification to the product should be approved by CDS-John Blue Company prior to use. CDS-John Blue Company will deny Warranty claims and liability in any situation involving misuse, abuse or modification.

Each new machine or component manufactured by CDS-John Blue Company through original buyer is warranted by CDS-John Blue Company to buyer and to any party or parties to whom buyer may resell, lease or lend the equipment to be free from defects in material and workmanship under normal use and service. This obligation of CDS-John Blue Company under this warranty is limited to the repair or replacement of defective parts or correction of improper workmanship of any parts of such equipment which shall within one year from the date of CDS-John Blue's original delivery thereof, be returned to CDS-John Blue's factory, transportation charges prepaid and which CDS-John Blue Company shall determine to its satisfaction upon examination thereof to have been thus defective. When it is impractical to return the defective parts of such equipment to CDS-John Blue's factory, then CDS-John Blue shall have no liability for the labor cost involved in repairing or replacing any such parts and shall be liable solely for supplying the material necessary to replace or repair the defective parts, provided that prior thereto CDS-John Blue Company shall have determined to its satisfaction that any such parts are thus defective.

This warranty shall not apply to any equipment which shall have been repaired or altered outside CDS-John Blue's factory in any way so as to affect its durability, nor which has been subjected to misuse, abuse, negligence or accident, or operated in any manner other than in accordance with operating instructions provided by CDS-John Blue Company. This warranty does not extend to repairs made necessary by the use of inferior or unsuitable parts or accessories, or parts or accessories not recommended by CDS-John Blue Company.

CDS-John Blue Company makes no warranties in respect to parts, accessories or components not manufactured by CDS-John Blue Company, same ordinarily being warranted separately by their respective manufacturers.

DIVISION OF ADVANCED SYSTEMS TECHNOLOGIES HUNTSVILLE, AL (256) 721-9090



CDS-John Blue Company
 Division of Advanced Systems Technology
 165 Electronics Blvd., Huntsville AL 35824
 Telephone: (256) 721-9090 • Fax (256)-721-9091
 Toll Free 1-800-253-2583